

ACCESSORIES

REPLACEMENT SEALS & REPAIR KITS

Both replacement seal kits and individual O-rings and back-up rings are available. Leakage between the female body half (coupling) and the male tip half (nipple) is an indication that the body O-ring needs replacement.

Field repair kits that include the body seal, a new poppet assembly and installation instructions are available for various couplings.



PART NUMBERS			
Complete Coupler	O-ring	Back-up Ring	Field Repair Kit
S101-1			
S105-1	S1060B-1	S1061T-1	
S101-2			
S101-2-6			
S105-2	S1060B-2	S1061T-2	
S105-2-6	S1060B-2	S1061T-2	
S101-3			
S101-3-8			
S105-3	S1060B-3	S1061T-3	
S105-3-8	S1060B-3	S1061T-3	
S101-4			
S101-4-10			
S105-4	S1060B-4	S1061T-4	
S105-4-10	S1060B-4	S1061T-4	
S101-6			S106-6RK
S101-6-12			S106-6RK
S105-6	S1060B-6	S1061T-6	S106-6RK
S105-6-12	S1060B-6	S1061T-6	S106-6RK
S101-8			S106-8RK
S101-8-16			S106-8RK
S105-8	S1060B-8	S1061T-8	S106-8RK
S105-8-16	S1060B-8	S1061T-8	S106-8RK
SH25-2(P)	S460-2		
SH25-14(P)	S460-2		
SH25-2-3P	S460-2		
S35-2P	S360-2	S361-2	
S35-3P	S360-3	S361-3	
S511-6-1/2(-STL)			S511-6RK
S515W-6-1/2(-STL)			S511-6RK
S515H-6-1/2(-STL)			S511-6RK
S511-6(-STL)			S511-6RK
S515W-6(-STL)			S511-6RK
S515H-6(-STL)			S511-6RK
S511-8(-STL)			S511-8RK
S515W-8(-STL)			S511-8RK
S515H-8(-STL)			S511-8RK
S511-10(-STL)			S511-10RK
S515W-10(-STL)			S511-10RK
S515H-10(-STL)			S511-10RK
S561-2			
S565-2	S5660B-2	S5661T-2	
S561-3			
S561-3-6			
S565-3	S5660B-3	S5661T-3	
S565-3-6	S5660B-3	S5661T-3	
S561-4			
S561-4-8			
S561-4-10			

PART NUMBERS			
Complete Coupler	O-ring	Back-up Ring	Field Repair Kit
S565-4	S5660B-4	S5661T-4	
S565-4-8	S5660B-4	S5661T-4	
S565-4-10	S5660B-4	S5661T-4	
S561-6			S566-6RK
S561-6-12			S566-6RK
S565-6	S5660B-6	S5661T-6	S566-6RK
S565-6-12	S5660B-6	S5661T-6	S566-6RK
S561-8			S566-8RK
S561-8-16			S566-8RK
S565-8	S5660B-8	S5661T-8	S566-8RK
S565-8-16	S5660B-8	S5661T-8	S566-8RK
SF491-3			SF491-3RK
FF491-3			FF491-3RK
FF491-3M			FF491-3RK
FF491-3-8			FF491-3RK
FF491-3-1/2			FF491-3RK
FF491-6			FF491-6RK
FF491-6-12			FF491-6RK
FFE491-4			FF491-6RK
FFE491-4-3/4			FF491-6RK
FFE491-4-10			FF491-6RK
FFE491-4-12			FF491-6RK
FFE491-6			FFE491-6RK
FFE491-6-1			FFE491-6RK
FFE491-6-16			FFE491-6RK
FFE491-8			FFE491-8RK
FFE491-8-20			FFE491-8RK
FFE491-8-114			FFE491-8RK
S25A-2(P)	S460-2		
S25-3(P)	S460-3		
S25-4(P)	S460-4		
S25-15(P)	S460-4		
S25-16(P)	S460-4		
S25-4(P)	S460-4		
S25F-6	S260-6		
S25-8P	S260-8		S206-8RK
S45-2(P)	S460-2		
S45-3(P)	S460-3		
S45-4(P)	S460-4		
S45-15(P)	S460-4		
S45-6(P)	S460-4		
S75-4(P)	S760-4		
S75-15(P)	S760-4		
S75-16(P)	S760-4		
S25-4-20	S170-4		
S25-15-20	S170-4		
S25-4-21P	S160-4		
S25-16-21P	S160-4		

Complete Coupler Numbers shown with a parenthesis indicate alternative part configurations