

REPLACEMENT SEALS & REPAIR KITS

Both replacement seal kits and individual O-rings and back-up rings are available. Leakage between the female body half (coupling) and the male tip half (nipple) is an indication that the body O-ring needs replacement.

Field repair kits that include the body seal, a new poppet assembly and installation instructions are available for various couplings.



| PART NUMBERS | | | |
|-------------------|----------|--------------|------------------|
| Complete Coupler | O-ring | Back-up Ring | Field Repair Kit |
| S101-1 | | | |
| S105-1 | S1060B-1 | S1061T-1 | |
| S101-2 | | | |
| S101-2-6 | | | |
| S105-2 | S1060B-2 | S1061T-2 | |
| S105-2-6 | S1060B-2 | S1061T-2 | |
| S101-3 | | | |
| S101-3-8 | | | |
| S105-3 | S1060B-3 | S1061T-3 | |
| S105-3-8 | S1060B-3 | S1061T-3 | |
| S101-4 | | | |
| S101-4-10 | | | |
| S105-4 | S1060B-4 | S1061T-4 | |
| S105-4-10 | S1060B-4 | S1061T-4 | |
| S101-6 | | | S106-6RK |
| S101-6-12 | | | S106-6RK |
| S105-6 | S1060B-6 | S1061T-6 | S106-6RK |
| S105-6-12 | S1060B-6 | S1061T-6 | S106-6RK |
| S101-8 | | | S106-8RK |
| S101-8-16 | | | S106-8RK |
| S105-8 | S1060B-8 | S1061T-8 | S106-8RK |
| S105-8-16 | S1060B-8 | S1061T-8 | S106-8RK |
| SH25-2(P) | S460-2 | | |
| SH25-14(P) | S460-2 | | |
| SH25-2-3P | S460-2 | | |
| S35-2P | S360-2 | S361-2 | |
| S35-3P | S360-3 | S361-3 | |
| S511-6-1/2(-STL) | | | S511-6RK |
| S515W-6-1/2(-STL) | | | S515-6RK |
| S515H-6-1/2(-STL) | | | S515-6RK |
| S511-6(-STL) | | | S511-6RK |
| S515W-6(-STL) | | | S515-6RK |
| S515H-6(-STL) | | | S515-6RK |
| S511-8(-STL) | | | S511-8RK |
| S515W-8(-STL) | | | S515-8RK |
| S515H-8(-STL) | | | S515-8RK |
| S511-10(-STL) | | | S511-10RK |
| S515W-10(-STL) | | | S515-10RK |
| S515H-10 (-STL) | | | S515-10RK |
| S561-2 | | | |
| S565-2 | S5660B-2 | S5661T-2 | |
| S561-3 | | | |
| S561-3-6 | | | |
| S565-3 | S5660B-3 | S5661T-3 | |
| S565-3-6 | S5660B-3 | S5661T-3 | |
| S561-4 | | | |
| S561-4-8 | | | |
| S561-4-10 | | | |

| PART NUMBERS | | | |
|------------------|----------|--------------|------------------|
| Complete Coupler | O-ring | Back-up Ring | Field Repair Kit |
| S565-4 | S5660B-4 | S5661T-4 | |
| S565-4-8 | S5660B-4 | S5661T-4 | |
| S565-4-10 | S5660B-4 | S5661T-4 | |
| S561-6 | | | S566-6RK |
| S561-6-12 | | | S566-6RK |
| S565-6 | S5660B-6 | S5661T-6 | S566-6RK |
| S565-6-12 | S5660B-6 | S5661T-6 | S566-6RK |
| S561-8 | | | S566-8RK |
| S561-8-16 | | | S566-8RK |
| S565-8 | S5660B-8 | S5661T-8 | S566-8RK |
| S565-8-16 | S5660B-8 | S5661T-8 | S566-8RK |
| SF491-3 | | | SF491-3RK |
| FF491-3 | | | FF491-3RK |
| FF491-3-8 | | | FF491-3RK |
| FF491-3-1/2 | | | FF491-3RK |
| FF491-6 | | | FF491-6RK |
| FF491-6-12 | | | FF491-6RK |
| FFE491-4 | | | FF491-6RK |
| FFE491-4-3/4 | | | FF491-6RK |
| FFE491-4-10 | | | FF491-6RK |
| FFE491-4-12 | | | FF491-6RK |
| FFE491-6 | | | FFE491-6RK |
| FFE491-6-1 | | | FFE491-6RK |
| FFE491-6-16 | | | FFE491-6RK |
| FFE491-8 | | | FFE491-8RK |
| FFE491-8-20 | | | FFE491-8RK |
| FFE491-8-114 | | | FFE491-8RK |
| S25A-2(P) | S460-2 | | |
| S25-3(P) | S460-3 | | |
| S25-4(P) | S460-4 | | |
| S25-15(P) | S460-4 | | |
| S25-16(P) | S460-4 | | |
| S25F-6 | S260-6 | | |
| S25-8P | S260-8 | | S206-8RK |
| S45-2(P) | S460-2 | | |
| S45-3(P) | S460-3 | | |
| S45-4(P) | S460-4 | | |
| S45-15(P) | S460-4 | | |
| S45-6(P) | S460-4 | | |
| S75-4 | S760-4 | | |
| S75-15 | S760-4 | | |
| S75-16 | S760-4 | | |
| S25-4-20 | S170-4 | | |
| S25-15-20 | S170-4 | | |
| S25-4-21P | S160-4 | | |
| S25-16-21P | S160-4 | | |

Complete Coupler Numbers shown with a parenthesis indicate alternative part configurations